

Single Gear Pump / HGP-05A-10 Series



HOW TO ORDER



HGP	05A	F	11	R	X	10
MODEL GEAR PUMP	GROUP 05A: SINGLE	MOUNTING TYPE F: FLAGE I: fONT	DISPLACEMENT (CC/REV)	ROTATING R:clockwise I: counter Clockwise	SHAF TYPE X: straigh	DESIGN NUMBER 10

SPECIFICATIONS

Model	Displacement CC/REV	Pressure bar (psi)		Speed (rpm)			Connecting (inch)		Weight (kgs)
		Working	Max.	Rate	Min.	Max.	IN	OUT	
HGP-05a-*03*-x-10	0.35	210 (3045)	250 (3625)	1800	800	3500	1/8	1/8	0.40
HGP-05A-*05*-X-10	0.56								
HGP-05A0*08*-X-10	0.85								
HGP-05A-*11***-X-10	1.13						1/4	1/4	

Single Gear Pump / HGP-1A-10 Series



HOW TO ORDER



HGP	A1	F	78	R	X	2B	10
MODEL GEARPUMP	GROUP 1A:SINGLE	MOUNTING TYPE F: FLAGE L:FOOT	DISPLACEMENT (CC/REV)	ROTATING R:Clockwise L:Counter Clockwise	SHAFT TYPE X: Straight Y:Spline	Flange type 2B: SAE2-bolt 4BD:D1N4bolt 4DE:EUR4BOLT	DESIGN NUMBER 10

SPECIFICATION

MODEL	DISPLACEMENT (CC/REV)	Pressure bar (psi)		Speed (rpm)			Connecting (inch)		Weight (kgs)
		Working	Max.	Rate	Min.	Max.	IN	OUT	
HGP-1A-*05*-x-10	.50	210 (3045)	250 (3625)	1800	1000	4500	3/8	3/8	1.00
HGP-1A-*08*-x-10	.80								
HGP-1A-*10*-x-10	1.00								
HGP-1A-*20*-x-10	2.00				600	4000			
HGP-1A-*26*-x-10	2.60								
HGP-1A-*30*-x-10	3.00								
HGP-1A-*40*-x-10	4.00								
HGP-1A-*50*-x-10	5.00				3200				
HGP-1A-*60*-x-10	6.00								
HGP-1A-*78*-x-10	7.80								
		175(2538)	210(3045)				1/2		1.40

Single Gear Pump / HGP-2A-10 Series



HOW TO ORDER



HGP	2A	F	12	R	X	4BJ	10
MODEL Gear Pump	GROUP 2A:Single	MOUNTING TYPE F:Flage L:Foot	DISPLACEMENT (CC/REV)	ROTATING R:Clockwise L: Counter Clockwise	SHAFT TYPE X: Straight Y:Spline	FLAGE TYPE 4BJ: JIS4-bolt	DESIGN NUMBER 10